

SAFETY CABINET

Yellow Red Blue

1



DO YOU KNOW

THE USE OF APPROVED SAFETY CANS IS YOUR FIRST LAYER OF PROTECTION AGAINST FIRE. STORAGE OF SAFETY CANS IN APPROVED SAFETY CABINETS PROVIDES YOUR SECOND LAYER OF PROTECTION.

Flammable liquid Storage Cabinet

One of the Major Causes for fires is improper storage and handling of flammable liquids and chemicals. HALLON Flammable Liquid Chemical Safety Cabinets, help you to properly store, classify each hazardous chemical, reduce risks and ensure personal and environmental safety.



- ◆ Constructed of 1.2mm, double-walled steel, along with 38mm of insulating air space for fire resistance. a double key set and/or accepts an optional padlock.
- ◆ three – point stainless steel bullet latching. The shelves safely direct spills to back and bottom of leak – tight, 50mm lower sump.
- ◆ dual vents, four adjustable levelling feet and a grounding connector. Fully painted inside and out with durable lead-free epoxy/polyester powder paint for chemical resistance.

Item	Capacity Gal/Ltr	Door type	HxWxD mm	N.W/kg	Adjustable Shelves/PCS
HL10004Y	4/15	single door	560*430*430	35	1
HL100012Y	12/45	single door	890*590*460	56	1
HL100022Y	22/83	single door	1650*590*460	85	2
HL100030Y	30/114	double doors	1120*1090*460	100	1
HL100045Y	45/170	double doors	1650*1090*460	138	2
HL100060Y	60/227	double doors	1650*860*860	165	2
HL100090Y	90/340	double doors	1650*1090*860	190	2
HL100110Y	110/410	double doors	1650*1500*860	270	2



- Isolate flammable liquids within the cabinet to prevent ignition.
- Promote good house-keeping practices by storing all flammable liquids together and away from non-compatible products.
- All flammable safety cabinets feature flame-arrestor vents and earthing points.
- Each flammable storage cabinet includes adjustable feet and shelving.
- The safety cabinet's base section captures any leaks and is easily accessible to retrieve spilt liquids.